BOONTON ELECTRONICS CORPORATION

INSTRUCTION MANUAL

MODEL 92C

RF MILLIVOLTMETER

92C
b-173

MP MASTER
MA25172

BOONTON ELECTRONICS CORPORATION
TEL: 201-887-5110
TWX: 710-986-8241
ROUTE 287 AT SMITH ROAD
PARSIPPANY, N.J. 07054 USA


BOONTON ELECTRONICS
RF MILLIVOLTMETER
RMS
VOLTS
dBm
50 Ω
MODEL 92C
PROBE
ZERO
FULL SCALE
mV
dBm
3000
1000
300
100
30
10
3
PWR
+20
+10
0
−10
−20
−30
−40
BOONTON ELECTRONICS CORPORATION
BOONTON ELECTRONICS
SAME SERIAL NO. PROBE
BOONTON ELECTRONICS

Model 92C



TABLE OF CONTENTS

CHAPTER		PAGE
I	SPECIFICATIONS	1
II	GENERAL DESCRIPTION	7
	2.1 GENERAL	7
	2.2 EQUIPMENT DESCRIPTION	8
	2.2.1 Wide Frequency Range	8
	2.2.2 Wide Voltage Range	8
	2.2.3 True RMS Response	9
	2.2.4 Low Noise	9
	2.2.5 Minimal Zero Adjustment	9
III	OPERATING PROCEDURE	10
	3.1 INSTALLATION PROCEDURE	10
	3.1.1 Operating Controls and Indicators	10
	3.2 OPERATING PROCEDURES	11
	3.2.1 Initial Operating Procedure	11
	3.3 OPERATING NOTES	12
	3.3.1 Overload Limits	12
	3.3.2 Connection for Measurements Below 100 MHz	12
	3.3.3 Connection for Measurement Above 100 MHz	12
	3.3.4 Low-Level Measurement	14
	3.3.5 Making the Zero Adjustment	14
	3.3.6 Signal Overload on 3 mV Range	14
	3.3.7 Temperature Effects	14
	3.3.8 Hum, noise and Spurious Pick-up	15
	3.4 LOW-FREQUENCY MEASUREMENTS	15
	3.5 CORRECTION CURVES FOR ACTUAL VOLTAGE vs METER READINGS	15
	3.6 CORRECTION CURVE FOR MODEL 91-8B	15
	3.7 CORRECTION CURVE FOR MODEL 91-14A	15
IV	THEORY OF OPERATION	18
	4.1 GENERAL	18
	4.1.1 RF Probe	19
	4.1.2 Attenuator and Amplifiers	19
	4.1.3 Synchronous Detector	19
	4.1.4 Shaping Amplifier	20
	4.1.5 Chopper-Driver Circuits	20
	4.1.6 Power Supply	20

TABLE OF CONTENTS (Cont'd)

CHAPTER		PAGE
V	MAINTENANCE	21
	5.1 PERIODIC CALIBRATION	21
	5.2 PRECAUTIONS WHEN CHECKING CALIBRATION	21
	5.3 CALIBRATION CHECK	21
	5.4 CALIBRATION PROCEDURE	21
	5.5 TROUBLE-SHOOTING	
	5.5.1 No meter indication, ZERO control has no effect	22
	5.5.2 All readings are abnormally low	23
	5.5.3 Readings are erratic on one range	23
	5.5.4 Pilot lamp lighted, instrument inoperative	23
	5.5.5 Pilot lamp dark, instrument inoperative	24
	5.5.6 Replacement of Probes	24

LIST OF ILLUSTRATIONS

FIGURE No.		PAGE
1	Input Resistance of RF Probe as a Function of Input Level and Frequency	5
2	Input Capacitance vs. Input Level of Model 91-12F Probe (at 10 MHz)	6
3	Typical VSWR of Model 91-12F Probe with Model 91-8B 50 Ω BNC Adapter	6
4	Typical VSWR of Model 91-12F Probe with Model 91-14A Type N Tee Adapter and Model 91-15A 50 Ω Termination	6
5	Method For Making Low-Inductance Connection to Test-Signal Point Directly Using the RF Probe	13
6	Assembly of Model 91-14A Type N Tee Adapter	13
7	Correction Curves, Actual Voltage vs. Meter	16
8A	Model 91-8B 50 Ω Adapter Correction Curve	17
8B	Model 91-14A Type N Tee Adapter Correction Curve	17
9	Model 92C Block Diagram	18

LIST OF ILLUSTRATIONS (Cont'd)

FIGURE No		PAGE
10	Calibration Instructions on Underside of Top Cover	25
List of Replaceable Parts		Following Text
Schematics		Endfold

CHAPTER I

SPECIFICATIONS

Voltage Range: 500 μV to 3V (300V up to 700 MHz with accessory 100:1 Voltage Divider) (see Table 1)

Full Scale Voltage Ranges: 3, 10, 30, 100, 300, 1000, and 3000 mV.

dBm Range: -50 to +23 dBm (+63 dBm up to 700 MHz with optional accessory, Model 91-7C 100:1 Voltage Divider)

Frequency Range: 10 kHz to 1.2 GHz (uncalibrated response to approximately 8 GHz).

Accuracy:

	10 kHz to 50 kHz	50 kHz to 150 MHz	150 MHz to 700 MHz	700 MHz to 1.2 GHz
	2% fs plus			
300 mV to 3 V	1% rdg			10% rdg
500 μV to 300 mV	2% rdg	1% rdg	3% rdg	7% rdg

Meter: 4-1/2-inch taut-band
Two linear voltage scales
0 to 3; 0.05 per division
0 to 10; 0.1 per division
One logarithmic dBm scale
-10 to +3; 0.2 per division max.

Meter Unrest: Typically, less than 1% on the 3 mV range.

Power: 115 to 230 V ±10%, 50 to 400 Hz, 4 W.

RFI: There is no detectable radiated or conducted leakage from instrument or probe.

Temperature: In accordance with ANSI (ASA) Spec. 39.7

Temperature Range	Temperature Influence	
	Instrument	RF Probe
Ref. 21° C to 25° C	0	0
Normal, 18° C to 30° C	0	± 1% rdg
Severe, 10° C to 40° C	± 1% rdg	±4% rdg

Waveform Response:	True rms response for input levels up to 30 mV (3V to 700 MHz with 100:1 Voltage Divider), with transition to peak-to-peak (calibrated in rms) at higher levels.
Crest Factor:	84 to 1.4 depending upon input level (see Table II).
Input Impedance:	See Figures 1 and 2.
VSWR:	Less than 1.15 to 1.2 GHz (Return Loss greater than 23 dB). See Figures 3 and 4.
Power Sensitivity:	5 nW, minimum detectable power in 50 ohms.
Dimensions:	5.2" H (without rubber feet), 8.3" W (1/2 of standard 19 inch rack module) 11.5" D (132 x 211 x 292 mm).
Weight:	Net 7.5 lbs. (3.4 kg) (with standard accessories) Shipping - 10 lbs. (4.6 kg)
Accessories Furnished:	Model 91-12F, RF Probe. RF Probe with low-noise cable and connector assembly for measurements from 10 kHz to 1.2 GHz; see Figures 1 and 2 for input resistance and capacitance.
	Model 91-13B, Probe Tip. Removable Probe Tip with grounding clip lead; for use up to approximately 100 MHz.
	Model 91-8B, 50Ω BNC Adapter. Use for measurements up to 600 MHz in a 50-ohm system, for VSWR see curve of Figure 3.
Warm-Up:	Warm-up period, 1 min. Adjust zero on 3 mV range when measuring below 30 mV.
Accessory Kit (Optional) Model 91-24A:	Model 91-6C, Unterminated BNC Adapter. Used for coaxial connection up to approximately 100 MHz, or to 400 MHz when fed from a 50-ohm source in an electrically short system.
	Model 91-7C, 100:1 Voltage Divider. Attenuates input signal by a factor of 100 (± 1%), permitting measurements up to 300 volts and extending the rms measuring range to 3 volts; increases input resistance by a factor of 1000; operates from 50 kHz to 700 MHz. Maximum input potential, 1000 volts, dc plus peak ac.
	Model 91-14A, 50Ω Tee Adapter. Type N Tee Connector; with Model 91-15A termination (see below) permits connecting into 50-ohm line; required for measurements above approximately 100 MHz: for VSWR see curve of Figure 4.
	Model 91-15A, 50Ω Termination. Type N 50-ohm termination for use with Model 91-14A Tee Connector.

Other Accessories (Optional) Available:

Model 91-4C, Special 1 kHz to 250 MHz RF Probe. Low-frequency probe for measurements ranging from 1 kHz to 250 MHz; input resistance essentially the same as that of Model 91-12F, RF Probe.

Model 91-16A, Unterminated Type N Adapter. May be used with all probes, except Model 91-23A. Used for coaxial connection up to approximately 100 MHz, or to 400 MHz when fed from a 50-ohm source in an electrically short system.

Model 92-1A, Rack Mounting Kit. Kit for mounting Model 92C as one-half of a module in a standard 19 inch rack.

IMPORTANT NOTE:

To exploit fully the capabilities of this instrument, the accessories listed below are required for the indicated ranges of operation.

Table 1. Required accessories

MEASURING RANGE	REQUIRED ACCESSORY	REMARKS
100 MHz to 600 MHz	Model 91-8B 50Ω Adapter for shielded connection to 50-ohm line; other impedances available on request.	Supplied as standard equipment with the Model 92C.
Above 600 MHz	Model 91-14A Tee Connector and 91-15A 50 Ω Termination for connection into 50-ohm line.	Available separately.
1 kHz to 250 kHz	Model 91-4C RF Probe.	Available separately.
Input levels up to 300V; rms response with levels to 3V.	Model 91-7C 100:1 Voltage Divider; operates over frequency range from 50 kHz to 700 MHz.	Available separately.

For details on the availability of these and other Boonton Electronics Accessories for RF Voltmeters, call on your local Boonton Electronics Sales Engineering Representative, or write directly to the factory at the address on the title page of this instruction book.

Table 2. Crest Factor

VOLTAGE RANGES (mV) AND CREST FACTORS						
VOLTAGE RANGE (mV)	3	10	30	300*	1000*	3000*
CREST FACTOR**	84 to 14	21 to 4.2	8.4 to 1.4	84 to 14	21 to 4.2	8.4 to 1.4

* With accessory 100:1 Voltage Divider (see Table 1).
**Maximum permissible ratio of peak to rms value of voltage.

STANDARD EQUIPMENT OPTIONS

92C-03 dBV option: dB scale is referred to 1 V.

92C-04 dBV option: dB scale, referred to 1 V, is uppermost.

92C-05 75 Ω dBm option: dBm scale is referred to 75 Ω: 75 Ω 91-8B/1 BNC adapter supplied.

92C-06 75 Ω dBm option: dBm scale, referred to 75 Ω, is uppermost; 75 Ω 91-8B/1 BNC adapter supplied.

92C-07 50 Ω dBm option: dBm scale, referred to 50 Ω, is uppermost.

92C-08 Rear signal input option.

92C-12 dBmV option: dBmV scale is uppermost.



Figure 1. Input Resistance of RF Probe as a Function of Input Level and Frequency



Figure 2. Input Capacitance vs. Input Level of Model 91-12F Probe (Measured at 10 MHz)



Figure 3. Typical VSWR of Model 91-12F Probe with Model 91-8B 50Ω BNC Adapter



Figure 4. Typical VSWR of Model 91-12F RF Probe with Model 91-14A Type N Tee Adapter and Model 91-15A 50Ω Termination

CHAPTER II

GENERAL DESCRIPTION

2.1 GENERAL. The Model 92C RF Millivoltmeter is a solid state, sensitive, rf millivoltmeter used for measurements from the low radio frequencies to the gigahertz region, and over a voltage range from 500 microvolts to 3 volts.

The Model 92C provides true rms response for input signals up to 30 millivolts, gradually approaching peak-to-peak response calibrated on the meter scale in rms above this level. It is characterized by high input impedance (see Figures 1 and 2), excellent stability, and low noise.

The Model 92C is particularly suitable for production and laboratory applications. It offers a convenient and accurate means for making a wide variety of measurements. Among the typical uses of the Model 92C are the following:

In transistor testing the instrument may be used to measure β, f_t, and other transistor parameters.

VSWR and return loss measurement using the Model 92C with bridge methods, directional couplers, and adjustable or slotted lines.

Gain and loss measurements in wide-band amplifiers, including such design characteristics as stage gain, flatness of the pass band, upper cut-off or corner frequency, negative feedback factors, and other parameters.

Proper adjustment of tuned circuits in narrow-band amplifiers.

The adjustment, measurement of performance, and evaluation of parameters of rf filters.

Measurement of vswr or return loss and attenuation of rf attenuators.

Measurement of output levels of signal generators, adjustment of baluns, harmonic distortion of rf signals, and adjustment of circuits for minimum voltage (null) or maximum voltage (peak).

The Model 92C has a basic accuracy of 1% rdg. + 2% fs. The standard features of the instrument are as follows:

Measures 500 μV to 3V* from 10 kHz to 1.2 GHz.
True rms response to 30 mV**
Convenient push-button ranging and half-rack packaging.
High input resistance, low input capacitance.
Overload protection to 400 Vdc, 10 Vac.
VSWR less than 1.15 up to 1.2 GHz.
* To 300 V, up to 700 MHz with accessory 100:1 divider.
** To 3V, up to 700 MHz with accessory 100:1 divider.

The characteristics of the instrument include: solid state chopper, high reliability, fast warm-up, lengthy intervals between calibrations, light weight, and all other advantages of solid state design.

2.2 EQUIPMENT DESCRIPTION. The instrument is sensitive, accurate, sturdily constructed, and protected against overloads. It will perform over extended periods of time without failure or need for recalibration. It is packaged as a compact (half-rack) bench instrument that can be easily mounted in a standard 19-inch rack using an inexpensive hardware kit.

Important input and accuracy specifications are stipulated on a reference plate fastened to the exterior top cover of the instrument. Clips for holding out-of-use accessories are provided at the rear of the instrument. Calibration instructions are reproduced on the underside of the top cover of the instrument.

The standard accessories furnished with the Model 92C include the following: A Model 19-12F RF Probe with a low-noise cable and connector assembly; a Model 91-8B 50-ohm BNC Adapter, and a Model 91-13B Probe Tip (removable) with a grounding clip lead.

A complete kit of probe accessories is available as optional equipment, including a storage case with space for the Model 91-12F RF Probe and the other standard accessories.

2.2.1 Wide Frequency Range. The calibrated range of the Model 92C extends from 10 kHz to 1.2 GHz, with uncalibrated response to beyond 8 GHz. Relative accuracy above 1.2 GHz is typically ±0.5 dB.

A Model 91-8B 50-ohm BNC Adapter is supplied as a standard accessory with the instrument for 50-ohm voltage measurements up to 600 MHz. A correction curve (Figure 8A) is included for frequencies above 50 MHz. For higher-frequency measurements and for through-line voltage measurements the optional accessory, Model 91-14A Tee Adapter, is recommended. It is designed to compensate for the rf probe capacitance and to present a good vswr (better than 1.15) up to 1.2 GHz. It may be used in conjunction with the Model 91-15A 50-ohm load for terminated voltage measurements. In a coaxial line its insertion loss is low; however, a chart (Figure 8B) is supplied showing loss vs. frequency.

An optional accessory, the Model 91-4C RF Probe, has a frequency range of 1 kHz to 250 MHz for lower-frequency applications.

2.2.2 Wide Voltage Range. The Model 92C has seven ranges, from 3 millivolts full scale to 3 volts full scale, arranged in a 3-10-30 sequence. No attenuator attachments are required for measurements up to 3 volts. While this range is ample for most rf voltage measurements, the capability of the instrument can be increased to 300 volts (up to 700 MHz) by using the optional accessory, Model 91-7C 100:1 Voltage Divider. Use of the Divider also increases the input resistance of the Model 91-4C RF Probe by a factor of greater than 100.

2.2.3 True RMS Response. The Model 92C provides true rms response for signal inputs below approximately 30 millivolts (below 3 volts, up to 700 MHz, with the Model 91-7C 100:1 Voltage Divider). As the input level increases, the waveform response gradually approaches peak-to-peak, calibrated on the meter scale in rms. Thus, in addition to making precise sinusoidal voltage measurements at all levels, the instrument measures non-sinusoidal or asymmetrical signals within the rms region without loss of accuracy.

2.2.4 Low Noise. The Model 92C has been designed and constructed to hold noise from all sources to a minimum.

The probe cable is of special low-noise design; a vigorous flexing causes only momentary, minor deflections on the most sensitive range. The Model 91-12F Probe is not sensitive to shock or vibration; even tapping on the probe barrel causes no visible deflection on any range.

Amplification takes place at 94 Hz, reducing susceptibility to any 50 or 60 Hz line-frequency fields.

2.2.5 Minimal Zero Adjustment. Zero adjustment is not required on the upper five sensitivity ranges of the Model 92C. For measurements on the lower two ranges, the ZERO control is set on the most sensitive range before operation. This control balances out small thermal voltages in the probe elements and, once adjusted, requires only infrequent checking during the course of subsequent measurements.

CHAPTER III

OPERATING PROCEDURE

3.1 INSTALLATION PROCEDURE. The Model 92C has been inspected and tested at the factory before packing, and is shipped ready for operation. If there is any indication of shipping damage, immediately notify the carrier before attempting to put the instrument into operation.

3.1.1 Operating Controls and Indicators. The controls and indicators installed on the Model 92C are shown in Table 3.

Table 3. Model 92C Controls and Indicators

COMPONENT	FUNCTION
(Symbol on Rear Panel)	This safety requirement symbol has been adopted by the International Electrotechnical Commission, Document 66 (Central Office) 3, paragraph 5.3 which directs that an instrument be so labeled, if, for the correct use of the instrument, it is necessary to refer to the instruction manual. In this case it is recommended that reference be made to the instruction manual when connecting the instrument to the proper power source. Verify that the right fuse is installed for the power available and that the switch on the rear panel 0.03A and 0.06A, 50-400 Hz, is set to the applicable operating voltage of 115 V or 230 V. Within a brief time, the use of this symbol will be acted upon by ANSI (ASA).
Fuse Holder and Fuse (Rear Panel)	A fuse holder is located on the rear panel for installing either a 1/16 ampere, 117 V, or a 1/32 ampere, 220 V, Bussman MDL SLO-BLO fuse.
Slide Switch (Rear Panel)	Switch which is set to 115 V or 230 V, according to the available power source. Be sure that the proper fuse is located in the fuse holder.

Table 3. Model 92C Controls and Indicators (Cont'd)

COMPONENT	FUNCTION
PWR ON	This switch turns on the instrument.
RANGE, FULL SCALE (mV and dBm) (Push-buttons)	These range push buttons, (3, 10, 30, 100, 300, 1000 and 3000 mV) and (-40, -30, -20, -10, 0, +10 and +20 dBm) select the voltage range.
PROBE (Jack)	The probe cable connects to the instrument through this PROBE jack. Always check that the knurled ferrule nut of the probe cable connection is tightened when in use.
ZERO (Control)	This control is used to zero the instrument.
Component Holders (Clips) (Rear Panel)	Three component holders or component clips are located on the rear panel for securing accessories which are not in use.
METER	A 4 1/2-inch taut-band meter with two linear voltage scales reading out 0 to 3 with 0.05 per division; 0 to 10 with 0.1 per division; and one logarithmic dBm scale reading out -10 to +3 with 0.2 per division maximum.

3.2 OPERATING PROCEDURES. The following paragraphs describe the initial operating procedure for the Model 92C, the various operating notes, and the recommended connection procedures.

3.2.1 Initial Operating Procedure. The Model 92C is put into service by the following procedure:

a. Check the panel meter zero position and, if necessary, adjust the mechanical zero control to align the pointer with the zero reference.

NOTE:

Check to see that the serial number of the probe to be used matches that of the particular model of the Model 92C. Each instrument is calibrated for its particular rf probe. Use of a probe other than that for which the instrument was calibrated may result in errors in measurement.

b. Connect the probe cable to the PROBE jack on the front panel.

c. Next, verify that the proper power source is available. The instrument should be plugged only into a power source having the voltage and frequency indicated on the instrument rear panel.

d. With the power cord plugged into the proper ac power source, turn the instrument on. The Model 92C is operational within 30 seconds.

3.3 OPERATING NOTES. While measuring with the Model 92C is a direct and straightforward process, there are certain precautions and procedures which MUST be observed to obtain satisfactory results.

3.3.1 Overload Limits. The Model 91-12F RF Probe supplied with the Model 92C is overload-protected to 10 volts, ac, and to 400 volts, dc. EXCEEDING THESE LIMITS MAY RESULT IN PERMANENT DAMAGE TO THE PROBE.

The Model 91-8B 50-ohm Adapter should not be subjected to continuous overload of more than 10 volts (dc + rms ac) to avoid excessive heating of the terminating resistor.

When voltages above these limits are likely to be encountered, the Model 91-7C 100:1 Voltage Divider is required. Maximum rating of the Voltage Divider is 1000 volts, dc + peak ac.

3.3.2 Connection for Measurements Below 100 MHz. The RF Probe supplied with the Model 92C is equipped with a detachable tip and ground lead. For measurements of signals below approximately 100 MHz, this tip provides a convenient means for both signal and ground connection.

3.3.3 Connection for Measurement above 100 MHz. For frequencies above 100 MHz, the probe tip should NOT be used with the Model 92C. Connection should be made directly to the center contact of the probe with the ground connection kept as short as possible (see Figure 5).

The connection recommendations outlined in Table 4 below should be followed to maintain specified accuracy.

Table 4. Connection Recommendations

FREQUENCY	SIGNAL CONNECTION
Up to 100 MHz	Probe Tip and grounding lead (supplied)
100 MHz to 250 MHz	Probe without tip (see Figure 5) (supplied)
250 MHz to 600 MHz	Probe with Model 91-8B 50Ω BNC Adapter (supplied)
Beyond 600 MHz	Probe with Model 91-14A Type N Tee Adapter and Model 91-15A Type N 50Ω Termination (see Figure 6) (optional accessories)



Figure 6. Assembly of Model 91-14A Type N Tee Adapter

3.3.4 Low-Level Measurement. The Model 92C has a sensitivity of 300 microvolts, and will provide reliable, reproducible measurements of signal levels as low as 500 microvolts.

When using the most sensitive range, a preliminary zero adjustment is required. On the 10 mV range, particularly for measurements above mid-scale, proper zero adjustment is less critical, although still recommended.

3.3.5 Making the Zero Adjustment. When the instrument is to be used on the 3 mV range, the following zero procedure applies:

a. Set the RANGE FULL SCALE selector to the 3 mV position.

b. See that no voltage is applied to the probe, and that the probe is adequately shielded from local fields (for test procedure, see paragraph 3.3.8).

c. Adjust the ZERO control to bring the reading toward a zero reference condition. Noise will cause the reading to fluctuate up to ±2% of full scale. Adjust the ZERO control so that the reading averages zero.

3.3.6 Signal Overload on 3 mV Range. On the most sensitive (3 mV) range, application of a large ac signal overloads the amplifier and a short time is required for the high-impedance input circuit to discharge. This effect is significant for signals above approximately 100 millivolts. Typically, application of a 1 volt signal will require a recovery time of about fifteen seconds before subsequent measurements may be made. It should be noted, however, that such overloads cause no damage to the equipment as long as they are within the limits outlined in paragraph 3.3.1.

3.3.7 Temperature Effects. The accuracy specifications for the Model 92C apply over temperatures from 50°F to 104°F. Outside of these limits, operation of the equipment is possible but appreciable inaccuracies can be expected. However, no permanent change in probe characteristics will result from any reasonable high or low temperature exposure.

It should be noted that inaccuracies of measurement resulting from temperature effects may occur shortly after soldering to the probe tip, or measuring with the probe in close proximity to sources of intense heat, such as vacuum tubes.

When making low-level measurements (below approximately 2 millivolts) it is important to make sure that the probe has attained a uniform temperature throughout its body. A temperature gradient between the inside and outside of the probe can generate a small thermal voltage that may add to the dc output of the detector diodes. This can be compensated for by turning off the signal source and re-adjusting the ZERO control.

3.3.8 Hum, Noise and Spurious Pick-up. When measuring low-level signals precautions should be taken to avoid the possibility of measurement errors from hum, noise, or stray rf pick-up. Although hum and low-frequency noise are attenuated at the input, it is still possible for unwanted high-level signals to cause errors. In some cases it may be necessary to provide extra shielding around the probe connections to reduce stray pick-up. Typical sources of spurious radiation are: induction or dielectric heating units, diathermy machines, local radio transmitters and grid dip meters.

3.4 LOW-FREQUENCY MEASUREMENTS. The Model 91-12F RF Probe supplied with the Model 92C provides measurements within the specified accuracy from 10 kHz to 1.2 GHz. For measurements at lower frequencies the Model 91-4C RF Probe is available. It operates over a frequency range from 1 kHz to 250 MHz. Important Note: After installing the Model 91-4C RF Probe, the Model 92C must be checked for accuracy of calibration, and recalibrated if required (see paragraphs 5.3 and 5.4).

3.5 CORRECTION CURVES FOR ACTUAL VOLTAGE vs. METER READINGS. Use the correction curves of Figure 7 to correct meter readings on the Model 92C and Model 92C Option Instruments.

3.6 CORRECTION CURVE FOR MODEL 91-8B. Use the correction curve of Figure 8A to make corrections when using the Model 91-8B, 50Ω BNC Adapter with the Model 92C and Model 92C Option Instruments.

3.7 CORRECTION CURVE FOR MODEL 91-14A. Use the correction curve of Figure 8B when using the Model 91-14A Type N Tee Adapter.



Down-Scale Correction (0 to 10 scale)



Down-Scale Correction (0 to 3 scale)

Figure 7. Correction Curves, Actual Voltage vs. Meter Reading



Figure 8A. Model 91-8B 50Ω BNC Adapter Correction Curve.



Figure 8B. Model 91-14A Type N Tee Adapter Correction Curve. Input voltage to tee adapter is indicated by voltmeter. Subtract the correction from the indicated value, in dB, to obtain output voltage of tee.

CHAPTER IV

THEORY OF OPERATION

4.1 GENERAL. The operating principles of the Model 92C are shown in the following block diagram. The essential elements of the instruments are the probe, chopper driver, chopper, attenuator, preamplifier, amplifier, pulse generator, synchronous detector, shaping amplifier, power supply, and a meter.



Figure 9. Block Diagram

4.1.1 RF Probe. The RF Probe embodies a full-wave diode detector which rectifies the signal under study to a dc voltage whose level is a function of the input level. While operating in the square-law region (below approximately 30 millivolts) the detector provides true rms response. As the input level increases beyond 30 millivolts, waveform response gradually approaches peak-to-peak, calibrated on the scale in rms.

In addition to increasing efficiency, use of full-wave rectification in the detector probe permits measurement of signals having highly asymmetrical waveforms without errors stemming from turn-over effect.

The diodes used in the RF Probe have been carefully selected for specific characteristics. The user is urged NOT to attempt their replacement with any off-the-shelf types. In case of damage to probe components, call on your local Boonton Electronics Sales Engineering Representative or the factory for instructions.

4.1.2 Attenuator and Amplifiers. The dc output of the probe is converted to ac by the chopper, and the resultant ac signal applied to the attenuator and amplifier sections. For each range the output voltage from the 2nd amplifier is approximately 3V peak-to-peak. This is accomplished by ranging both the attenuation and the gain of the second amplifier in the following manner:

RANGE	$\frac{1}{\text{ATTN}}$	GAIN 2nd AMP.
3 mV	1	100
10	1	10
30	1	1
100	0.15	1
300	0.04	1
1000	0.01	1
3000	0.004	1

The preamplifier has a constant gain of X100, and is designed for very low input noise. Both amplifiers have wide bandwidths and are stabilized by large amounts of negative feedback.

4.1.3 Synchronous Detector. The amplified ac signal from the second detector is converted to dc by the synchronous detector. The peak-to-peak amplitude is derived from a shunt-series capacitor storage circuit using JFET switches. The synchronous detector is driven by pulses generated in the chopper-driver circuit, thus assuring exact synchronization. The characteristics of the detector determine the effective bandwidth of the amplifier-detector combination and allow modification of the bandwidth for different range conditions. The detector also provides conversion without offset.

4.1.4 Shaping Amplifier. The conversion of rf to dc in the probe is non-linear, the response being virtually square-law for the lowest ranges and gradually becoming quasi-linear for the 3V range. The shaping amplifier converts the non-linear output of the synchronous detector to a linear output by using a segmental approximation to the exact correction. The shaping amplifier is actually an operational amplifier so connected that, as the signal increases at its output, its gain is reduced by successively paralleling resistors across the feedback resistors. The number of segments required adequately to linearize the response varies from 6 for the "square-law" ranges down to 2 for the 3V range. The output of the shaping amplifier is +10V which drives the panel meter.

4.1.5 Chopper-Driver Circuits. The chopper-driver block provides all of the drive signals required by the instrument. The chopper frequency is obtained by dividing the output of a unijunction oscillator by two. The oscillator also generates the switching pulse for the synchronous detector. Diode gating feeds the pulse to the proper JFET depending upon chopper phase.

4.1.6 Power Supply. The power supply converts the ac input power to regulated +15V and -15V outputs. Each supply is protected by current limiting against accidental short circuits. The +15V supply is a zener-biased follower, and no adjustment is provided. The -15V supply is referred to a 6.2V zener, and the voltage is adjustable to -14.9V, ±0.1V.

CHAPTER V

MAINTENANCE

5.1 PERIODIC CALIBRATION. The Model 92C is designed to provide trouble-free operation over extended periods of time. However, as with any precision instrument, the instrument should be checked periodically to verify proper calibration. To make such calibration checks, the following equipment is required:

a. A reliable signal source of 200 kHz to 500 kHz with less than 1% distortion at levels up to 3 volts.

b. A precision ac voltmeter.

c. A precision dc voltmeter capable of measuring -15.0V, ±0.1%.

5.2 PRECAUTIONS WHEN CHECKING CALIBRATION. When checking the calibration of an instrument having the sensitivity and bandwidth of the Model 92C, it is essential to take precautions against errors resulting from stray pick-up voltages. (See paragraph 3.3.8.) A well-shielded signal source must be used in conjunction with coaxial connections to both the Model 92C and the standard reference meter. Even with a well-shielded generator and connections, it is sometimes possible for the reference meter to pick up stray rf signals and feed them into the probe. It is advisable to test for this condition by disconnecting the standard meter and noting any change in level.

5.3 CALIBRATION CHECK. Using the equipment listed in paragraph 5.1, check the calibration of the Model 92C on each range, using a test voltage equal to the full scale value. If the check reveals that recalibration is required, the procedure outlined in paragraph 5.4 should be followed.

5.4 CALIBRATION PROCEDURE. The Model 92C should be calibrated at room temperature (21° to 25°C) after a minimum warmup of one minute.

A calibration outline is provided inside the top cover of the instrument (see Figure 10). The adjustment references listed below are the same as those recorded on the top cover.

NOTE

Check the mechanical zero on the Model 92C with the power off before proceeding with the following adjustments.

Adjustment No. 1. Measure the -15.0V dc supply voltage at Test Point No. 5 located on the main amplifier board to the left of R145. Adjust R145 to -15V ±0.1V.

Adjustment No. 2. Set the RANGE FULL SCALE SELECTOR to the 3 mV Range and zero the instrument as described in paragraph 3.3.5.

Adjustment No. 3. Set the RANGE FULL SCALE SELECTOR to the 30 mV Range and adjust R296 for a zero meter reading.

Adjustment No. 4. Set the RANGE FULL SCALE SELECTOR to the 3 mV Range (zero as in Adjustment No. 2 above), apply 3.00 mV, ±0.2%, input and adjust R208 for a 3.00 mV reading.

Adjustment No. 5. Set the RANGE FULL SCALE SELECTOR to the 10 mV Range (zero as in Adjustment No. 2 above), apply 10.0 mV, ±0.2%, input and adjust R220 for a 10.0 mV reading.

Adjustment No. 6. Set the RANGE FULL SCALE SELECTOR to the 30 mV Range, apply 30.0 mV, ±0.2%, input and adjust R228 for a 30.0 reading.

Adjustment No. 7. Set the RANGE FULL SCALE SELECTOR to the 100 mV Range, apply 100 mV, ±0.2%, input and adjust R236 for a 100 mV reading.

Adjustment No. 8. Set the RANGE FULL SCALE SELECTOR to the 300 mV Range, apply 300 mV, ±0.2%, input and adjust R255 for a 300 mV reading.

Adjustment No. 9. Set the RANGE FULL SCALE SELECTOR to the 1000 mV Range, apply 1000 mV, ±0.2%, input and adjust R268 for a 1000 mV reading.

Adjustment No. 10. Set the RANGE FULL SCALE SELECTOR to the 3000 mV Range, apply 3000 mV, ±0.2%, input and adjust R281 for a 3000 mV reading.

5.5 TROUBLE-SHOOTING. The conservative design of the Model 92C results in an instrument requiring a minimum of repair and maintenance. Should trouble develop, however, the procedures outlined in the paragraphs following will help in locating the defective component or circuit. They are listed in order of probability commencing with the RF Probe, which may be subjected to an accidental voltage overload severe enough to damage its diodes. Unless a fault is obvious enough to be immediately apparent, it is suggested that the trouble-shooting procedure be followed in the order given.

5.5.1 No meter indication, ZERO control has no effect: This symptom may indicate an open diode in the RF Probe. If another probe is available, substitution for the suspected probe will quickly determine whether or not this has happened. If no other probe is available, follow the procedure below.

a. Remove the probe connector from the front panel jack.

b. Jump the two terminals of the jack with a short piece of wire, and test the operation of the ZERO control on the 3 mV Range. If this control will now zero the meter, the trouble is probably in the probe. This can be confirmed by making a resistance measurement with an ohmmeter between the two pins on the probe connector. Using a high range on the ohmmeter, a good probe will show approximately 20 kΩ in one direction and virtually infinite resistance in the other. If a diode is open, resistance in either direction will be extremely high.

5.5.2 All readings are abnormally low: This is an indication that a probe diode has short-circuited under a severe overload. This condition cannot easily be verified with a VOM: if another probe is available, substitution for the suspected probe will quickly check this.

NOTE

The diodes used in the RF Probes are highly specialized components. Their replacement with other diodes should not be attempted. If the tests above verify that a diode has failed, the probe should be returned to the factory for repair.

5.5.3 Readings are erratic on one range:

a. Check the tightness of the miniature connectors on the cable wiring between the two PC boards. If one of them appears loose on the pin, crimp with a pair of long-nosed pliers.

b. Locate the miniature calibration potentiometer associated with the defective range in the row along the top edge of the vertical PC board (see Calibration Chart). Test it with an ohmmeter for correct resistance, and for good rotor contact. Refer to the Schematic or the Table of Replaceable Parts for the resistance value.

c. Test the contacts on the appropriate section of the panel range switch for firm contact and low resistance.

d. Using the Schematic, methodically trace the operating circuits of the instrument with an oscilloscope and a multitester. Waveforms, dc and ac voltages, and other values are included on the schematic.

5.5.4 Pilot lamp lighted, instrument inoperative:

a. Remove the top and bottom covers of the instrument to allow easy access to all points of the circuitry. The vertical PC board may also be removed from the case and allowed to rest across the side frames; the cable is long enough to permit this, except for the two leads to the LED pilot lamp (brown and white/brown). These may be left unconnected.

b. With the instrument turned on, check the dc output of the power supply. The +15 volts is available at the front terminal of C114, and the -15 volts at C115. Both voltages are measured to the chassis.

c. If there is no dc output, check the terminations of the three wires from the power transformer on the back panel to the printed circuit board (red, red/yellow, and red/white) to see that they grip the pins firmly. Measure the ac voltages between these pins, and then the dc voltages through the power supply section to the output points.

d. If the normal dc output voltages are measured in Step b, the trouble should be sought in the other sections of the instrument. It is suggested that the Block Diagram, Figure 9, be consulted in conjunction with the Schematics at the back of the Instruction Book. Using an oscilloscope and voltmeter, a thorough analysis of the circuits should be made, working back from the output to the input. Dc and ac voltages, as well as waveforms, are indicated in the Schematics for critical points in the circuits.

5.5.5 Pilot lamp dark, instrument inoperative: This normally indicates primary power failure.

a. Check the position of the line voltage switch on the rear panel to be sure that it is in the correct position for the line voltage used.

b. Remove the line fuse from its socket on the rear panel and test it. See that it is the right size for the available line voltage.

c. Remove the instrument's top cover by taking out the screw on the top rear of the cover. Examine the terminations of the two leads (grey and white/grey) running to the rear terminals of the panel power switch. See that the miniature connectors grip the pins firmly.

WARNING: These leads carry the ac line voltage. Unplug the instrument's power cable before touching them.

d. With the instrument still unplugged, test the panel power switch for continuity.

e. With the power applied, methodically trace the operating circuits with oscilloscope and VOM, with particular attention to the range in question.

NOTE: Removal of the bottom cover allows access to all parts of the circuitry. The vertical PC board may be removed by taking out the mounting screws from the four metal mounting pillars. The interconnecting wires are long enough to allow the board to function outside the case. The two short wires to the bottom of the panel range switch (brown and white/brown) are the supply leads to the LED pilot lamp; these must be unplugged before removing the PC board, and may be left unconnected during testing.

5.5.6 Replacement of Probes: The Model 92C has been calibrated at the factory with the probe supplied with the instrument. Both instrument and probe should have the same serial number. Should another probe be used, or the original probe be repaired, the instrument's calibration MUST be checked. In some cases full recalibration will be required (see procedure in Par. 5.4). Similarly, if the RF Probe supplied with the instrument is exchanged for a Model 91-4C Low Frequency Probe, recalibration may be required.

CALIBRATION INSTRUCTIONS

ADJ NO	R	FUNCTION	RANGE mV	INPUT ±0.2%	ADJUST TO
1	145	-15V ADJ	-	-	-15V ±0.1V
2	401	FRONTPANEL ZERO	3	0	0
3	296	DC ZERO	30	0	0
4	208	RANGE ADJ	3	3mV	3mV
5	220	RANGE ADJ	10	10mV	10mV
6	228	RANGE ADJ	30	30mV	30mV
7	236	RANGE ADJ	100	100mV	100mV
8	255	RANGE ADJ	300	300mV	300mV
9	268	RANGE ADJ	1000	1000mV	1000mV
10	281	RANGE ADJ	3000	3000mV	3000mV

Figure 10. Calibration Instructions

TABLE OF REPLACEABLE PARTS

Reference		Description			BEC Part No.
A201	Op Amp	LM301			535002
A202	"	LM302			535003
C101	Capacitor, PE	100nF	200V	±10%	234005
C102	" EL	10µF	20V	±20%	283205
C103	" MIC	100pF	500V	±5%	200001
C104	" EL	10µF	20V	±20%	283205
C105	" EL	33µF	15V	±20%	283206
C106	" EL	10µF	20V	±20%	283205
C107	" MET	1.0µF	100V	±20%	236007
C108	" EL	1.0µF	35V	±20%	283199
C109	" EL	50µF	25V		283159
C110	" "	"	"		"
C111	" PE	100nF	200V	±10%	234005
C112	" EL	250µF	40V		283207
C113	" "	"	"		"
C114	" EL	100µF	25V		283105
C115	" "	"	"		"
C201	Capacitor, PC	100nF		10%	234046
C202	" PE	6.8nF		10%	234044
C203	" MICA	100pF		5%	200001
C204	" "	"		"	"
C205	" "	"		"	"
C206	" PE	18nF		5%	234064
C207	" MICA	100pF		5%	200001
C208	" EL	50µF	25V		283159
C209	" "	"	"		"
C210	" CER	10nF			224119
C211	" MICA	33pF		±5%	200049
C212	" CER	10nF			224119
C213	" PE	22nF			230101
C214	" PC	100nF		10%	234046
C215	" "	"		"	"
C216	" CER	10nF			224119
C217	" "	"			"
C401	Capacitor, PC	100nF	50V	±10%	234046
C402	" "	"	"	"	"

Reference		Description	BEC Part No.
CR101	Diode	FD300	530052
CR102	"	1N914	530058
CR103	"	"	"
CR104	Diode, Zener	1N5243B	530101
CR105	" "	1N5235B	530089
CR106	"	1N914	530058
CR107	Bridge, Rectifier		532013
CR108	Diode	1N914	530058
CR109	"	"	"
CR110	"	"	"
CR111	"	"	"
CR112	Diode, Zener	1N5246B	530090
CR113	"	1N5234B	530093
CR201	Diode	1N914	530058
CR202	"	"	"
CR203	"	"	"
CR204	"	"	"
CR205	"	"	"
CR206	"	"	"
CR207	"	"	"
CR208	"	"	"
CR209	"	MV5025	
CR210	"	1N914	530058
CR211	"	"	"
CR212	"	"	"
CR213	"	"	"
CR214	"	"	"
CR215	"	FD300	530052
CR216	"	1N914	530058
CR217	"	"	"
F401	Fuse	1/16A 117V	545518
		or	
F401	"	1/32A 220V	545522
M401	Meter		554238

TABLE OF REPLACEABLE PARTS (Cont'd)

Reference		Description	BEC Part No.
Q101	Transistor, Field Effect	2N5459	528019
Q102	" "	"	"
Q103	" "	"	"
Q104	" "	TIS58	528038
Q105	"	HDGP100	528057
Q106	" Field Effect	2N5459	528019
Q107	" Factory Selected		528044
Q108	"	2N5088	528047
Q109	"	2N5087	528042
Q110	"	MPSA66	528048
Q111	"	2N5087	528042
Q112	"	2N5088	528047
Q113	" Field Effect	TIS58	528038
Q114	" "	"	"
Q115	" "	"	"
Q116	" "	2N5459	528019
Q117	" "	"	"
Q118	Not Used		
Q119	"	MPSA66	528048
Q120	"	2N3903	528024
Q121	"	2N3905	528025
Q122	" Field Effect	2N5459	528019
Q123	" "	"	"
Q124	"	2N4921	528034
Q125	"	2N4918	528033
Q126	"	2N5087	528042
Q201	Transistor	2N5087	528042
Q202	"	2N4871	528051
Q203	"	2N5087	528042
Q204	"	"	"
Q205	"	MPSA20	528043
Q206	"	2N5087	528042
Q207	"	"	"
Q208	"	2N5088	528047
Q209	"	"	"
Q210	"	"	"
Q211	"	2N5087	528042
Q212	"	"	"
Q213	"	"	"
Q214	"	MPSA20	528043
Q215	"	2N5087	528042
Q216	"	MPSA20	528043
Q217	"	2N5087	528042

TABLE OF REPLACEABLE PARTS (Cont'd)

Reference		Description	BEC Part No.
Q218	Transistor	2N5087	528042
Q219	"	MPSA20	528043
Q220	"	2N5087	528042
Q221	"	"	"
Q222	"	MPSA20	528043
Q223	"	2N5087	528042
Q224	"	"	"
Q225	"	MPSA12	528052
Q226	"	TIS58	528038
Q227	"	"	"

TABLE OF REPLACEABLE PARTS (Cont'd)

Reference		Description			BEC Part No.
R101	Resistor, Comp.	1MΩ	5%	1/2W	301159
R102	" "	Factory Selected			
R103	" "	2KΩ	5%	1/2W	301094
R104	" MF	5.62MΩ	1%	1/4W	325397
R105	" "	24.3KΩ	1%	3/8W	340405
R106	" "	80.6KΩ	1%	3/8W	326467
R107	" "	374KΩ	1%	3/8W	340547
R108	" "	294KΩ	1%	3/8W	340535
R109	" "	1.0MΩ	1%	3/8W	326700
R110	" Comp.	91KΩ	5%	1/2W	301134
R111	" "	47KΩ	5%	1/2W	301127
R112	" "	33KΩ	5%	1/2W	301123
R113	" "	300KΩ	5%	1/2W	301146
R114	" MF	169Ω	1%	3/8W	340147
R115	" Comp.	10KΩ	5%	1/2W	301111
R116	" "	"	"	"	"
R117	" "	33KΩ	5%	1/2W	301123
R118	" MF	15.0KΩ	1%	3/8W	340378
R119	" Comp.	15KΩ	5%	1/2W	301115
R120	" "	3.6KΩ	5%	1/2W	301100
R121	" Comp.	3KΩ	5%	1/2W	301098
R122	" "	1MΩ	5%	1/2W	301159
R123	" "	2.7KΩ	5%	1/2W	301097
R124	" "	5.6KΩ	5%	1/2W	301105
R125	" "	"	"	"	"
R126	" "	1KΩ	5%	1/2W	301087
R127	" "	5.1KΩ	5%	1/2W	301104
R128	" "	15KΩ	5%	1/2W	301115
R129	" "	1KΩ	5%	1/2W	301087
R130	" "	10KΩ	5%	1/2W	301111
R131	" MF	30.1KΩ	1%	3/8W	326397
R132	" "	3.01KΩ	1%	3/8W	340297
R133	" "	301Ω	1%	3/8W	340176
R134	" "	33.2Ω	1%	3/8W	340063
R135	" Comp.	1MΩ	5%	1/2W	301159
R136	" "	2K	5%	1/2W	301094
R137	" "	24KΩ	5%	1/2W	301120
R138	" "	"	"	"	"
R139	" "	2K	5%	1/2W	301094
R140	" "	8.2Ω	5%	1/2W	301505
R141	" "	"	"	"	"
R142	" "	100Ω	5%	1/2W	301063
R143	" "	"	"	"	"
R144	" MF	3.92KΩ	1%	3/8W	340311
R145	" Var.	1KΩ	20%	1/2W	311257
R146	" MF	4.75KΩ	1%	3/8W	340321

TABLE OF REPLACEABLE PARTS (Cont'd)

Reference		Description			BEC Part No.
R201	Resistor, Comp.	150KΩ	5%	1/2W	301139
R202	" "	10KΩ	5%	1/2W	301111
R203	" MF	100KΩ	1%	3/8W	340478
R204	" Comp.	10KΩ	5%	1/2W	301111
R205	" MF	51.1KΩ	1%	3/8W	340443
R206	" "	2.74KΩ	1%	3/8W	340292
R207	" Comp.	Selected			
R208	" Var.	1KΩ	±20%		311284
R209	" Comp.	10KΩ	5%	1/2W	301111
R210	" MF	28.7KΩ	1%	3/8W	340414
R211	" "	200KΩ	1%	3/8W	340515
R212	" "	1.0MΩ	1%	3/8W	326700
R213	" Comp.	100Ω	5%	1/2W	301063
R214	" "	33KΩ	5%	1/2W	301123
R215	" MF	40.2KΩ	1%	3/8W	326401
R216	" "	191KΩ	1%	3/8W	340512
R217	" Comp.	100KΩ	5%	1/2W	301135
R218	" "	3.3KΩ	5%	1/2W	301099
R220	" Var.	1KΩ	±20%		311284
R221	" MF	29.4KΩ	1%	3/8W	340415
R222	" "	95.3KΩ	1%	3/8W	340476
R223	" Comp.	4.7KΩ	5%	1/2W	301103
R224	" "	10KΩ	5%	1/2W	301111
R225	" MF	28.0KΩ	1%	3/8W	340412
R226	" "	64.9KΩ	1%	3/8W	340456
R227	" Comp.	10KΩ	5%	1/2W	301111
R228	" Var.	1KΩ	±20%		311284
R229	" Comp.	270KΩ	5%	1/2W	301145
R230	" MF	26.1KΩ	1%	3/8W	340408
R231	" "	46.4KΩ	1%	3/8W	340438
R232	" Comp.	10KΩ	5%	1/2W	301111
R233	" "	390KΩ	5%	1/2W	301149
R234	" MF	45.3KΩ	1%	3/8W	326403
R235	" "	2.74KΩ	1%	3/8W	340292
R236	" Var.	1KΩ	±20%		311284
R237	" Comp.	18KΩ	5%	1/2W	301117
R238	" "	15KΩ	5%	1/2W	301115
R239	" "	10KΩ	5%	1/2W	301111
R240	" "	47KΩ	5%	1/2W	301127
R241	" MF	21.5KΩ	1%	3/8W	340398
R242	" "	240KΩ	1%	3/8W	340524
R243	" "	26.1KΩ	1%	3/8W	340408
R244	" "	154KΩ	1%	3/8W	340501
R245	" Comp.	10KΩ	5%	1/2W	301111

TABLE OF REPLACEABLE PARTS (Cont'd)

Reference		Description			BEC Part No.
R246	Resistor, MF	54.9KΩ	1%	3/8W	340447
R247	" "	191KΩ	1%	3/8W	340512
R248	" "	31.6KΩ	1%	3/8W	340418
R249	" "	82.5KΩ	1%	3/8W	340468
R250	" "	178KΩ	1%	3/8W	326514
R251	" "	31.6KΩ	1%	3/8W	340418
R252	" Comp.	12KΩ	5%	1/2W	301113
R253	" MF	17.8KΩ	1%	3/8W	340388
R254	" MF	2.74KΩ	1%	3/8W	340292
R255	" Var.	1KΩ	±20%		311284
R256	" Comp.	100KΩ	5%	1/2W	301135
R257	" MF	24.3KΩ	5%	1/2W	340405
R258	" "	232KΩ	1%	3/8W	340522
R259	" "	95.3KΩ	1%	3/8W	340476
R260	" "	453KΩ	1%	3/8W	340557
R261	" Comp.	100KΩ	5%	1/2W	301135
R262	" "	12KΩ	5%	1/2W	301113
R263	" MF	200KΩ	1%	3/8W	340515
R264	" "	634KΩ	1%	3/8W	340575
R265	" "	31.6KΩ	1%	3/8W	340418
R266	" "	14.3KΩ	1%	3/8W	340377
R267	" "	2.74KΩ	1%	3/8W	340292
R268	" Var.	1KΩ	±20%		311284
R269	" Comp.	100KΩ	5%	1/2W	301135
R270	" MF	31.6KΩ	1%	3/8W	340418
R271	" Comp.	100KΩ	5%	1/2W	301135
R272	" MF	34.8KΩ	1%	3/8W	340423
R273	" "	523KΩ	1%	3/8W	340565
R274	" Comp.	2KΩ	5%	1/2W	301094
R275	" "	27KΩ	5%	1/2W	301121
R276	" MF	162KΩ	1%	3/8W	340503
R277	" "	806KΩ	1%	3/8W	340587
R278	" Comp.	3KΩ	5%	1/2W	301098
R279	" MF	10KΩ	1%	3/8W	326376
R280	" "	2.74KΩ	1%	3/8W	340292
R281	" Var.	1KΩ	±20%		311284
R282	" Comp.	1.6KΩ	5%	1/2W	301092
R283	" "	12KΩ	5%	1/2W	301113
R284	" "	4.7KΩ	5%	1/2W	301103
R285	" "	470Ω	5%	1/2W	301079
R286	" "	750 Ω	5%	1/2W	301084
R287	" "	100KΩ	5%	1/2W	301135
R288	" MF	127KΩ	1%	3/8W	340491
R289	" "	604KΩ	1%	3/8W	340572
R290	" Comp.	150KΩ	5%	1/2W	301139
R291	" "	510KΩ	5%	1/2W	301152

TABLE OF REPLACEABLE PARTS (Cont'd)

Reference		Description			BEC Part No.
R292	Resistor, Comp.	15KΩ	5%	1/2W	301115
R293	" "	10KΩ	5%	1/2W	301111
R294	" "	4.7KΩ	5%	1/2W	301103
R295	" MF	49.9 kΩ	1%	3/8W	340438
R296	" Var.	2KΩ	±20%		311285
R297	" Comp.	100KΩ	5%	1/2W	301135
R298	" "	2KΩ	5%	1/2W	301094
R299	" "	3KΩ	5%	1/2W	301098
R401	Resistor, Var.	5KΩ			311283
R402	" MF	100KΩ	1%	3/8W	340478
R403	" "	"	"	"	"
R404	" Comp.	Factory Selected			
S201	Switch	PB10			465169
S402	Switch, Slide				465134
T401	Transformer	Power			446052
IC401	Switch, Solid-State	Factory Selected			534020


TEST POINT
WAVEFORM
5 & 10mV RANGES ONLY
TO SWITCH P.C BOARD
PROBE
ZERO
NOTES:
1. CAPACITANCE VALUES IN μF UNLESS OTHERWISE SPECIFIED.
2. RESISTANCE VALUES IN OHMS & 1/2 WATT, UNLESS OTHERWISE SPECIFIED. (EXCEPT R105-R109, R114, R115, R131-R134, R144 & R146-R148 WHICH SHALL BE 1/8 WATT).
3. FACTORY SELECTED VALUE.
4. EXTERNAL MARKINGS
5. SIGNAL PATH.
6. FEEDBACK PATH.
7. SIGNAL PATH FOR 100, 300, 1000 & 3000mV RANGES ONLY.
8. TEST CONDITIONS: DC VOLTAGES INDICATED ARE NOMINAL VALUES ONLY.
10mV RANGE
10mV SIGNAL
9. LAST NUMBERS USED:
R146 C115
R403 C402
10. NUMBERS NOT USED:
CR111 Q118
11. TEST POINTS.

BOONTON ELECTRONICS CORPORATION

MODEL 92C
Schematic, Amplifier
E830513B



BOONTON ELECTRONICS CORPORATION

MODEL 92C
Schematic, Switch
E830529C

WARRANTY

Boonton Electronics Corporation warrants its products to the original Purchaser to be free from defects in material and workmanship and to operate within applicable specifications for a period of one year from date of shipment, provided they are used under normal operating conditions. This warranty does not apply to active devices that have given normal service, to sealed assemblies which have been opened, or to any item which has been repaired or altered without our authorization.

We will repair or, at our option, replace at no charge any of our products which are found to be defective under the terms of this warranty. Except for such repair or replacement, we will not be liable for any incidental damages or for any consequential damages, as those terms are defined in Section 2-715 of the Uniform Commercial Code, in connection with products covered by this warranty.

BOONTON ELECTRONICS CORPORATION

Telephone: 201-887-5110
TWX: 710-986-8241
Route 287, Parsippany, N. J. – 07054

WARRANTY